

PSPACE Command — GstarCAD 2027

3740 kbadmin September 25, 2026 [Command Reference](#) 0 9

PSPACE Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > P Command > PSPACE

Function Description:

This command is used to switch from model space in a layout viewport to paper space.

As one part of designing a layout, layout viewports can be created, which contains different views of the model at different scales. When switching from paper space to model space (MSPACE), users can edit models and views in the current layout viewport. Users can also make a layout viewport become the current viewport by double clicking the internal area of the viewport; as well they can switch to paper space by double clicking the external area of viewport. Users can also switch between different layouts and the model tab at the bottom of the drawing area.

Command Access:

Menu: /

Ribbon: /

Toolbar: /

Command: PSPACE

Alias: PS

Command Prompts: /

Related References?

- [Commands about Layouts](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3740>