

LWEIGHT Command — GstarCAD 2027

3798 kbadmin September 25, 2026 [Command Reference](#) 0 8

LWEIGHT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > L Command > LWEIGHT

Function Description:

This command is used to set the current lineweight, display options, and lineweight units. The [Lineweight Settings dialog box](#) is displayed. If you enter -LWEIGHT at the Command prompt, options are displayed.

Command Access:

Menu: Format > Lineweight...

Ribbon: Home > Properties > LINEWEIGHT CONTROL

Toolbar: Properties > LINEWEIGHT CONTROL

Command: LWEIGHT

Alias: LW

Command Prompts:

/

Related References?

- [Commands about Lineweights](#)
- [Commands about Controlling Object Display](#)

Related Concepts?

- [About Lineweights](#)

Related Tasks?

- [To Set the Current Lineweight](#)
- [To Display or Hide Lineweights](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3798>