

PERSPECTIVECLIP System Variable — GstarCAD 2027

3830 kbadmin September 25, 2026 [System Variable Reference](#) 0 10

PERSPECTIVECLIP System Variable

[GstarCAD 2027](#) · [System Variables](#)

Function Description:

The PERSPECTIVECLIP system variable is used to determine the location of eyepoint clipping.

Type	Real
Saved in	Registry
Initial value	5.0000
Range	0.01 ~ 10.0

This system variable determine the eyepoint location by percentage. If selected a much smaller value, the Z value of object will be compressed to target viewport and beyond. If selected a value such as 0.5, it clips at a near location from eyepoint in viewport. Under extremely condition, 0.1 may be suitable. It is recommended to set a larger value, such as 5.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3830>