

PROPOBJLIMIT System Variable — GstarCAD 2027

PROPOBJLIMIT System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > P System Variables > PROPOBJLIMIT

Function Description:

The PROPOBJLIMIT system variable is used to limit the number of objects that can be changed at one time using the Properties and Quick Properties palettes.

Type	Integer
Saved in	User-settings
Initial value	25000
Range	0~32767

Other versions with matching text

[2025](#) · [2026](#)