

PROXYGRAPHICS System Variable — GstarCAD 2027

PROXYGRAPHICS System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > P System Variables > PROXYGRAPHICS

Function Description:

The PROXYGRAPHICS system variable is used to specify whether to save images in proxy to drawings.

Type	Integer
Saved in	Drawing
Initial value	1
Range	0,1

System Variable Value:

- 0:** do not save images in proxy to drawings, but only display the frame.
- 1:** save images in proxy to drawings.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

