

# CENTERLTYPEFILE System Variable — GstarCAD 2027

3939 kbadmin September 25, 2026 [System Variable Reference](#) 0 24

## CENTERLTYPEFILE System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > C System Variables > CENTERLTYPEFILE

### Function Description:

The CENTERLTYPEFILE system variable is used to specify the loaded linetype library file used to create center marks and centerlines.

|               |            |
|---------------|------------|
| Type          | String     |
| Saved in      | Drawing    |
| Initial value | "acad.lin" |

The CENTERLTYPEFILE system variable applies only to center marks and centerlines created with CENTERMARK and CENTERLINE commands. This system variable determines the .lin file of the CENTERLTYPE setting used by the CENTERMARK and CENTERLINE commands.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3939>