

COLORTHEME System Variable — GstarCAD 2027

COLORTHEME System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > C System Variables > COLORTHEME

Function Description:

The COLORTHEME system variable is used to control the interface theme color. You can set the ribbon, palette, and other interface elements to different theme colors.

Type	Integer
Saved in	Registry
Initial value	0
Range	0~1

System Variable Value:

- 0: Displays the dark theme
- 1: Displays the light theme

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3963>