

# ATTOUT Command — GstarCAD 2027

4026 kbadmin September 25, 2026 [Command Reference](#) 0 9

## ATTOUT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > A Command > ATTOUT

### Function Description:

Exports block attribute values to an external file in tab-delimited ASCII format.

### Command Access:

**Menu:** Express > Blocks > Export Attribute Information

**Ribbon:** Express > Blocks > Export Attribute Information

**Toolbar:** /

**Command:** ATTOUT

**Alias:** /

### Command Prompts:

/

Once performed ATTOUT command, specifies file name and save path in the "Enter output filename" dialog box, then command line prompts:

Select object: Specify the blocks whose attributes you want to export.

The block names and attributes are exported to the named file. If the file already exists, you are prompted before it is overwritten. You can easily view attributes in a spreadsheet format and edit individual attribute values. Then you can enter the new values into the drawing file, using the ATTIN command.

---

## Related Tasks?

- [To Work With Express Tools](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4026>