

Autolayer Dialog Box — GstarCAD 2027

4038 kbadmin September 25, 2026 [Command Reference](#) 0 10

Autolayer Dialog Box

[GstarCAD 2027](#) · [Command Reference](#)

Commands > A Command > AUTOLAYER > Autolayer Dialog Box

Function Description:

This command allows you to customize and predefine the associated layer of a command to streamline drafting workflow.

Dialog Box

Options:

Layer List

Displays the command name and the corresponding automatic layer settings. The command name, layer name and important attributes can be set. The command name can use the uniform character. For example, * dim * indicates the annotation command with dim in all command names.

Creates a layer setting.

Deletes layer setting.

Enable Autolayer

When this check box is checked, the software will automatically assign layers during drawing according to the settings. If it is not checked, it will not work. Pressing the auto layer button on the bottom status bar has the same effect.

Save As Default

After customized settings, you can click this button to replace the currently used ini file with SUPPORTautolayer.ini to be applied to subsequent edits of the drawing..

Export Config

Saves the user's settings as a text file that can be used in other drawings or when imported by others.

Import Config

Read the settings file saved by the user and read the settings into the dialog box.

Clear Settings

Leaves the
autolayer list empty.

Other versions with matching text

[2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4038>