

SETVAR Command — GstarCAD 2027

4064 kbadmin September 25, 2026 [Command Reference](#) 0 7

SETVAR Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > S Command > SETVAR

Function Description:

This command is used to list or change the values of system variables.

Command Access:

Menu: Tools > Inquiry > Set Variable

Ribbon: Home > Utilities > Set Variable

Toolbar: /

Command: SETVAR

Alias: SET

Command Prompts:

Enter variable name or [?]:

Variable name

Specifies the name of the system variable to be set. Users can also change the system variable by entering its name and new value under the command prompt.

?

Lists all system variables and their current settings in the drawing.

Related References?

- [Commands about the Application Window](#)

Related Tasks?

- [To Enter Commands](#)
- [To Enter System Variables on the Command Line](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4064>