

BREAKLINE Command — GstarCAD 2027

4144 kbadmin September 25, 2026 [Command Reference](#) 0 10

BREAKLINE Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > B Command > BREAKLINE

Function Description:

This command is used to create a breakline, a polyline that includes the breakline symbol. The options within this command are provided to control the relative size and appearance of the breakline symbol and an extension of the polyline beyond the selected start and end points.

Command Access:

Menu: Express > Draw > Breakline Symbol

Ribbon: Express > Modify > Breakline Symbol

Toolbar: ET: Edit >

Breakline Symbol

Command: BREAKLINE

Alias: /

Command Prompts:

Specify first point for breakline or [Block/Size/Extension/sPecify line for breakline]:

Block

Determines the block to be used as the breakline symbol.

Size

Determines the size of the breakline symbol.

Extension

Determines the length of the line extension beyond selected points.

Specify line for breakline

Specifies location for break symbol. Specifies the point on the line segment to specify the location of the breakline symbol.

Related Tasks[?]

- [To Work With Express Tools](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4144>