

CHAMFEREDGE Command — GstarCAD 2027

4181 kbadmin September 25, 2026 [Command Reference](#) 0 6

CHAMFEREDGE Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > C Command > CHAMFEREDGE

Function Description:

Bevels the edges of 3D solids and surfaces.

Command Access:

Menu: /

Ribbon: /

Toolbar: /

Command: CHAMFEREDGE

Alias: /

Command Prompts:

Select an edge or
[Loop/Distance]:

Select an Edge

Selects a single solid or surface edge to chamfer.

Distance1

Sets the distance of the first chamfer edge from the selected edge. The default value is 1.

Distance2

Sets the distance of the second chamfer edge from the selected edge. The default value is 1.

Loop

Chamfers all edges on a single face. For any edge, there are two possible loops. After selecting a loop edge you are prompted to accept the current selection or choose the next loop.

Expression

Controls the chamfer distance with a mathematical expression.

Related Concepts?

- [About Chamfers](#)

Related Tasks?

- [To Work With Chamfers](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4181>