

COPYM Command — GstarCAD 2027

4221 kbadmin September 25, 2026 [Command Reference](#) 0 10

COPYM Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > C Command > COPYM

Function Description:

This command is used to copy multiple objects with Repeat, Divide, Measure and Array options.

Command Access:

Menu: Express > Modify > Multiple Copy

Ribbon: /

Toolbar: ET: Standard Tools > Multiple Copy

Command: COPYM

Alias: /

Command Prompts:

Select object:

Base point:

Second point or [Repeat (last)/Divide/Measure/Array (dynamic)/Undo] <Exit>:

Repeat

Repeats the last copy using the same offset distance.

Divide

Linear divide option. Prompts for an additional point and the number of copies to make. Makes evenly spaced copies of the selected objects between the base point and the second selected point.

Measure

Linear measure option. Prompts for an additional point and the distance between copies. Makes evenly spaced copies at the specified distance between the base point and the second selected point.

Array

Displays the Array Options prompt:

Pick Pick/Measure/Divide <Pick>:

- Pick: Allows you to interactively specify array elements. Prompts for an angle and then prompts for a point to establish row and column offset distances.
 - Measure: Allows you to specify a box to fill with copies of the selected objects. Prompts for an angle, a point to establish row or column offsets and an additional box corner point. The base point is used as the first corner of the box.
 - Divide: Allows you to specify a box to fill with copies of the selected objects. Prompts for an angle, and a point to establish the second box corner point. The base point is used as the first corner of the box. Then prompts for the number of rows and the number of columns.
-

Related Tasks²

- [To Work With Express Tools](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4221>