

DCALIGNED Command — GstarCAD 2027

4321 kbadmin September 25, 2026 [Command Reference](#) 0 7

DCALIGNED Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > D Command > DCALIGNED

Function Description:

Constrains the distance between two points on an object or between two points on different objects.

Command Access:

Icon:

Menu Item: Parametric(P) > Dimensional Constrains(D) > Aligned(A)

Ribbon: Parametric > Dimension > Aligned

Toolbar: /

Command Line: DCALIGNED

Command Alias: /

Command Prompts:

Specify first constraint point or [Object(O)/Point & line(P)/2Lines(2L)]

<Object>: Specifies the first point of the object to be constrained.

Specify second constraint point: Specifies the second point of the object to be constrained.

Operation Steps:

1. Adds aligned constraints by selecting two ends of a line or two points on different objects as shown.

2. The distance between the object's endpoints is constrained.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4321>