

DCDIAMETER Command — GstarCAD 2027

4324 kbadmin September 25, 2026 [Command Reference](#) 0 17

DCDIAMETER Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > D Command > DCDIAMETER

Function Description:

Constrains the diameter of a circle or an arc.

Command Access:

Menu Item: Parametric(P) > Dimensional Constrains(D) > Diameter(D)

Ribbon: Parametric > Dimension > Diameter

Toolbar: /

Command Line: DCDIAMETER

Command Alias: /

Command Prompts:

Select arc or circle: Specifies an arc or a circle to be constrained.

Specify dimension line location:

Operation Steps:

1. Select circles as shown to add diameter constraints.

2. The diameter of the circle will be constrained.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4324>