

# DCLINEAR Command — GstarCAD 2027

4328 kbadmin September 25, 2026 [Command Reference](#) 0 9

## DCLINEAR Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > D Command > DCLINEAR

### Function Description:

Constrains the horizontal or vertical distance between two points.

### Command Access:

Icon:

Menu Item: /

Ribbon: Parametric > Dimension > Linear

Toolbar: /

Command Line: DCLINEAR

Command Alias: /

### **Command Prompts:**

Specify first constraint point or [Object(O)]: Specifies the first point of the object to be constrained.

Specify second constraint point: Specifies the second point of the object to be constrained.

### **Operation Steps:**

1. Select the two ends of the horizontal and vertical lines respectively as shown in the figure to add linear constraints.

2. The horizontal or vertical distance between an object's endpoints is constrained.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4328>