

DELCONSTRAINT Command — GstarCAD 2027

4336 kbadmin September 25, 2026 [Command Reference](#) 0 7

DELCONSTRAINT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > D Command > DELCONSTRAINT

Function Description:

Removes all constraints from the selected object.

Command Access:

Menu Item: Parameters (P) > Delete Constraints (L)

Ribbon: Parameters > Delete Constraints

Toolbar: /

Command Line: DELCONSTRAINT

Command Alias: /

Command Prompts:

Delete Constraints: Removes all constraints from the selected objects.

Operation Steps:

1☐As shown in the figure (which is not provided here), select the object(s) from which you want to remove all constraints.

2☐Execute the DELCONSTRAINT command, and all the constraints associated with the selected object(s) will be deleted, leaving the object(s) without any geometric constraints.

Other versions with matching text

[2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4336>