

DIMOVERRIDE Command — GstarCAD 2027

4366 kbadmin September 25, 2026 [Command Reference](#) 0 5

DIMOVERRIDE Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > D Command > DIMOVERRIDE

Function Description:

This command is used to control the override values of system variable used in selected dimensions. Users can override a specified dimensioning system variable for selected dimensions or clear the overrides of selected dimension objects, they can also return to the settings defined by their dimension style.

Command Access:

Menu: Dimension > Override

Ribbon: Annotation > Dimension > DIMOVERRIDE

Toolbar: /

Command: DIMOVERRIDE

Alias: DOV

Command Prompts:

Enter dimension variable name to
override or [Clear overrides]:

Enter Dimension Variable name to Override

Overrides
the value of the specified dimensioning system variable.

Clear Overrides

Clears
any overrides on selected dimensions. The dimension objects return to the settings
defined by their dimension style.

Related References[?]

- [Commands about
Dimension Style Overrides](#)

Related Tasks[?]

- [To Apply Dimension Style Overrides](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4366>