

Work with Linetypes — GstarCAD 2027

4490 kbadmin September 25, 2026 [User Guide](#) 0 21

Work with Linetypes

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Create and Modify Objects > Control the Properties of Objects > Work with Linetypes

To make your drawing easier to read or to distinguish objects visually, you can use linetypes.

[Overview of Linetypes](#)

[Load Linetypes](#)

You can load the linetypes from the linetype files(*.lin) when you start your project or when you need them.

[Set the Current Linetype](#)

The current linetype is shown in the Linetype control on the Properties toolbar and all objects you draw will use the current linetype.

[Change the Linetype of an Object](#)

An object's linetype can be changed in three different ways, you can move, choose another linetypes or a different linetype explicitly for object.

[Control Linetype Scale](#)

The linetype can be changed to different scales by using the global scale factor and object scale factor.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4490>