

Add Column — GstarCAD 2027

4494 kbadmin September 25, 2026 [User Guide](#) 0 9

Add Column

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Table Tools > Add Column

The BGZL function can add new columns to the table.

Operation steps:

- 1.Start the command.
- 2.Specify the direction of the new column.
3. The system will add a new column on the right side of the table.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4494>