

Change Text Case — GstarCAD 2027

4528 kbadmin September 25, 2026 [User Guide](#) 0 7

Change Text Case

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Text tools > Change Text Case

The TCASE command is used to change the case of selected text, mtext, attributes and dimension text.

Command line prompts as follows :

Select object: Use a selection method to select annotation objects

Execute this command, start "TCASE - change text case" dialog box ,select an option.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4528>