

Character Break — GstarCAD 2027

4533 kbadmin September 25, 2026 [User Guide](#) 0 4

Character Break

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Text tools > Character Break

The WZDD command is used to break at the specified position, suitable for all single line text.

Operation steps:

- 1.Start the command.
- 2.Select the text to break.
- 3.Specify the position for the break.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4533>