

Delete Column — GstarCAD 2027

4543 kbadmin September 25, 2026 [User Guide](#) 0 4

Delete Column

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Table Tools > Delete Column

The BGSF function can delete columns you specified.

Operation steps:

- 1.Start the command.
- 2.Specify the cell of column for delete.
- 3.System will delete the column you specified.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4543>