

Extend to Nested Objects — GstarCAD 2027

4566 kbadmin September 25, 2026 [User Guide](#) 0 4

Extend to Nested Objects

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Blocks > Extend to Nested Objects

The BEXTEND command is used to extend objects such as line segment, arc, polyline or ray to a block. Objects would be extended to a block as close as possible if they cannot intersect with each other.

Command line prompts as follow:

Select objects or <select all>: Select one or more blocks and press ENTER

Select the object to Extend or Shift-select to Trim or [Edge/Fence/Crossing/Project]:

Select object(s) or enter an option and press ENTER

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4566>