

List Xref/Block Properties — GstarCAD 2027

4588 kbadmin September 25, 2026 [User Guide](#) 0 18

List Xref/Block Properties

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Blocks > List Xref/Block Properties

The XLIST command is used to list the type, block name, layer name, color and linetype of a nested object in a block or an xref. After selecting an external reference, the "Xref/Block object" dialog box will display attributes of specified blocks and xref, including object type, block name, color and linetype.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4588>