

Move/Copy/Rotate — GstarCAD 2027

4593 kbadmin September 25, 2026 [User Guide](#) 0 2

Move/Copy/Rotate

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Modify > Move/Copy/Rotate

The MOCORO command is used to move, copy, rotate, and scales object(s) with a single command.

Command line prompts as follows:

Select objects: Select object(s) and press Enter

Base point: Specify a base point

[Move/Copy/Rotate/Scale/Base/Undo]<eXit>: Once an option is specified

Options

Move: Move object(s).

Copy: Make multiple copies of object(s).

Rotate: Rotate object(s).

Scale: Dynamically scale object(s).

Base: Specifies a base point for object(s) to be moved, copied, scaled or rotated.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4593>