

Reset Dim Text Value — GstarCAD 2027

4601 kbadmin September 25, 2026 [User Guide](#) 0 18

Reset Dim Text Value

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Dimension > Reset Dim Text Value

The DIMREASSOC command is used to restore a measurement value to overridden or modified dimension text.

Command line prompts as follows:

Select object: Select dimension objects with non-associative text or press ENTER to quit

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4601>