

Text Align — GstarCAD 2027

4621 kbadmin September 25, 2026 [User Guide](#) 0 22

Text Align

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Text tools > Text Align

As the name describes, the TEXTALIGN function is used to align text. You can select several texts in your drawing to align along X or Y coordinates, or along a line of specific direction.

For example, when we create a table or part list and some contents are not in the correct location, using this tool improves the efficiency of adjusting text. After the command is started, a message will display:

Please select object:

Then select the text(s) to be aligned:

After selecting the text(s), a message will display: Select the align method: X axis (X) / Y axis (Y) / Two points (P):

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4621>