

Unmask Text — GstarCAD 2027

4633 kbadmin September 25, 2026 [User Guide](#) 0 20

Unmask Text

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Express tool > Text tools > Unmask Text

The TEXTUNMASK command is used to remove mask from text that has been masked with the TEXTMASK command.

Command line prompts as follow:

Select text or MText object from which mask is to be removed.

Select object: Use an object selection method.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4633>