

DGNIMPORTMAX System Variable — GstarCAD 2027

DGNIMPORTMAX System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DGNIMPORTMAX

Function Description:

The DGNIMPORTMAX system variable is used to set the maximum number of converting elements when importing a DGN file.

Type	Integer
Saved in	Registry
Initial value	10000000

System Variable Value:

- 0:** turn off the limit
- >0:** set the limit for the number of elements

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

