

DIMCLRT System Variable — GstarCAD 2027

4675 kbadmin September 25, 2026 [System Variable Reference](#) 0 13

DIMCLRT System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMCLRT

Function Description:

The DIMCLRT system variable is used to specify color for dimension text.

Type	Integer
Saved in	Drawing
Initial value	0

This color can be any valid color serial numbers.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4675>