

# DIMEXO System Variable — GstarCAD 2027

## DIMEXO System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DIMEXO

### Function Description:

The DIMEXO system variable is used to specify the distance that the extension line offsets origin.

|               |                                     |
|---------------|-------------------------------------|
| Type          | Real                                |
| Saved in      | Drawing                             |
| Initial value | 0.0625(Imperial) or 0.6250 (Metric) |

The DIMEXO system variable value determines the minimum offset for constant length of extension lines.

### Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)