

DWGCHECK System Variable — GstarCAD 2027

DWGCHECK System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > D System Variables > DWGCHECK

Function Description:

The DWGCHECK system variable is used to check whether there exists potential problem when opening drawings.

Type	Integer
Saved in	Registry
Initial value	1
Range	0,1,2,3

System Variable Value:

- 0:** if a drawing that you try to open has a potential problem, you are warned before the drawing is opened
- 1:** if a drawing that you try to open has a potential problem, or if it was saved by an application other than one based on RealDWG, you are warned before the drawing is opened
- 2:** if a drawing that you try to open has a potential problem, you are notified at the Command prompt
- 3:** if a drawing that you try to open has a potential problem, you are notified at the Command prompt. If the drawing has a potential problem and the drawing was saved by an application other than one based on RealDWG, you are warned before the drawing is opened

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4768>