

CLIPROMPTLINES System Variable — GstarCAD 2027

4822 kbadmin September 25, 2026 [What's New](#) 0 8

CLIPROMPTLINES System Variable

[GstarCAD 2027](#) · [Whats New](#)

Function Description:

The CLIPROMPTLINES system variable is used to set how many temporary prompt lines for a single command are displayed above the command window.

Type	Integer
Saved in	Registry
Initial value	3

By default, the command window displays a single prompt line. A temporary prompt history displays above the command window while a command is in progress. Enter a value from 0 - 50 to specify the maximum number of lines displayed in the prompt history for a single command.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4822>