

DCCONVERT Command — GstarCAD 2027

4838 kbadmin September 25, 2026 [What's New](#) 0 14

DCCONVERT Command

[GstarCAD 2027](#) · [Whats New](#)

Function Description:

Converts associative dimensions to dimensional constraints.

Command Access:

Menu Item: /

Ribbon: Parametric > Dimension > Convert

Toolbar: /

Command Line: DCCONVERT

Command Alias: /

Command Prompts:

Select associative dimensions to convert: Specifies the associative dimensions to be converted to dimensional constraints.

Operation Steps:

1. As shown in the figure, the left side is the dimensional constraints, and the right side is the constraint parameters.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4838>