

DCHORIZONTAL Command — GstarCAD 2027

4842 kbadmin September 25, 2026 [What's New](#) 0 16

DCHORIZONTAL Command

[GstarCAD 2027](#) · [Whats New](#)

Function Description:

Constrains the X distance between points on an object, or between two points on different objects.

Command Access:

Icon:

Menu Item: Parametric(P) > Dimensional Constrains(D) > Horizontal(H)

Ribbon: Parametric > Dimension > Horizontal

Toolbar: /

Command Line: DCHORIZONTAL

Command Alias: /

Command Prompts:

Specify first constraint point or [Object(O)]: Specifies the first point of the object to be constrained.

Specify second constraint point: Specifies the second point of the object to be constrained.

Operation Steps:

1. Select both ends of the horizontal line as shown to add horizontal constraints.

2. The horizontal distance between the object's endpoints is constrained.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4842>