

GC_DZTEXT — GstarCAD 2027

4881 kbadmin September 25, 2026 [What's New](#) 0 16

GC_DZTEXT

[GstarCAD 2027](#) · [Whats New](#)

Innovative Features > GC_DZTEXT

Function Description:

This command is used to accomplish kinds of incremental methods for text. The incrementation dialog box is displayed.

Command Access:

Menu: Text>Text Incremental Copy

Ribbon: Annotation > Text > Text Incremental Copy

Toolbar: ET: Texts Tools > Text Incremental Copy

Command: GC_DZTEXT

Alias: /

Command Prompts:

Selected Number/Alpha to
Increase<To Esc, press RIGHT>:

Dialog Box Options:

Distance

Specify incremental Distance, you can input value directly or single click the button on the right to specify by the crosshair.

Amount

If do not specify Amount, the system will calculate the amount according to the initial points of the crosshair.

Incrementation

Specify the incrementation.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4881>