

Rotate Cursor — GstarCAD 2027

4926 kbadmin September 25, 2026 [What's New](#) 0 6

Rotate Cursor

[GstarCAD 2027](#) · [Whats New](#)

The cursor can rotate anti-clockwise by 0 degree or 45 degree.

Side Line

Command Entry:RTCUR1

Operation steps:

- 1.Start the command.
- 2.Select the reference segment and system will align the X axis of the cursor to the selected segment.

Real Time Rotate

Command Entry:RTCUR

Operation steps:

1.After executing the command, the command line prompts as below.

2.You can use the AWSD four keys to control the cursor direction until you are satisfied and press enter.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4926>