

ACTRECPATH System Variable — GstarCAD 2027

4959 kbadmin September 25, 2026 [Command Reference](#) 0 9

ACTRECPATH System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The ACTRECPATH system variable is used to specify paths for storing new action macros.

Type	Strings
Saved in	Registry
Initial value	Unknown

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=4959>