

Add Row — GstarCAD 2027

5033 kbadmin September 25, 2026 [Command Reference](#) 0 8

Add Row

[GstarCAD 2027](#) · [Command Reference](#)

The BGZH function can add rows to the table.

Operation Steps:

- 1.Start the command.
- 2.Specify the position of the new row.
- 3.The system will add a row below the point you specified.

Other versions with matching text

[2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5033>