

CCONSTRAINTFORM System Variable — GstarCAD 2027

5089 kbadmin September 25, 2026 [Command Reference](#) 0 6

CCONSTRAINTFORM System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The CCONSTRAINTFORM system variable is used to control which to be applied to objects, the annotative constraint or dynamic constraint.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

- 0: dynamic
- 1: annotative

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5089>