

CONSTRAINTNAMEFORMAT System Variable — GstarCAD 2027

5121 kbadmin September 25, 2026 [Command Reference](#) 0 9

CONSTRAINTNAMEFORMAT System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The CONSTRAINTNAMEFORMAT system variable is used to control the text styles of dimension constrains.

Type	Integer
Saved in	Registry
Initial value	2
Range	0,1,2

System Variable Value:

- 0: name
- 1: value
- 1: expressions

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5121>