

CPROFILE System Variable — GstarCAD 2027

5127 · kbadmin · September 25, 2026 · [Command Reference](#) · 0 8

CPROFILE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The CPROFILE system variable is used to display current configuration name.
(Read-Only)

Type	Strings
Saved in	Registry
Initial value	<<Unnamed Profile>>

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5127>