

CVPORT System Variable — GstarCAD 2027

CVPORT System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The CVPORT system variable is used to change identification code in current viewport.

Type	Integer
Saved in	Drawing
Initial value	2

System Variable Value:

Users can change current viewport by setting the CVPORT system variable, first they should meet the following conditions:

1. The specified identification code should be one active viewport code.
2. The cursor has not been locked and it can move to viewport when executing a command.
3. The Tablet mode has turned off.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)