

Change the Lineweight of an Object — GstarCAD 2027

5155 kbadmin September 25, 2026 [Command Reference](#) 0 5

Change the Lineweight of an Object

[GstarCAD 2027](#) · [Command Reference](#)

To change the lineweight of an object, you can do :

- If an object's lineweight is set to BYLAYER, move it to another layers with a different lineweight, the object will acquire the lineweight of the new layer.
- If an object's lineweight is set to BYLAYER, you can modify the lineweight of the layer the object is on.
- Choose another lineweights for an object.

If you change the current lineweight setting on the Properties toolbar from BYLAYER to a specific lineweight, all newly created object's lineweight will be set to the new lineweight.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5155>