

Coordinate Point — GstarCAD 2027

5287 kbadmin September 25, 2026 [Command Reference](#) 0 11

Coordinate Point

[GstarCAD 2027](#) · [Command Reference](#)

The DIMCOORD command is used to dimension the point coordinate in the drawing.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5287>