

# DEFLPLSTYLE System Variable — GstarCAD 2027

5310 kbadmin September 25, 2026 [Command Reference](#) 0 8

## DEFLPLSTYLE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

### Function Description:

The DEFLPLSTYLE system variable is used to specify the default plot styles for all layers when opening a drawing which created in a earlier version, or for Layer 0 when creating a new drawing without using a drawing template.

|               |          |
|---------------|----------|
| Type          | Strings  |
| Saved in      | Registry |
| Initial value | Normal   |

When the drawing is open and the PSTYLEPOLICY set to be 1, the DEFLPLSTYLE is readable and its default value is "BYCOLOR". If the PSTYLEPOLICY set to be 0, the DEFLPLSTYLE is writable and its default value is "NORMAL".

Users can use CONVERTPSTYLES command to convert current drawing to be named plot styles or color dependent plot styles.

### Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5310>