

DGNIMPORTMAX System Variable — GstarCAD 2027

5315 kbadmin September 25, 2026 [Command Reference](#) 0 18

DGNIMPORTMAX System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DGNIMPORTMAX system variable is used to set the maximum number of converting elements when importing a DGN file.

Type	Integer
Saved in	Registry
Initial value	10000000

System Variable Value:

- 0:** turn off the limit
- >0:** set the limit for the number of elements

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5315>