

DIMALTF System Variable — GstarCAD 2027

5322 kbadmin September 25, 2026 [Command Reference](#) 0 15

DIMALTF System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMALTF system variable is used to control the multiplier of alternate units.

Type	Real
Saved in	Drawing
Initial value	25.4000(Imperial) or 0.0394 (Metric)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5322>