

DIMEXE — GstarCAD 2027

5348 kbadmin September 26, 2026 [Command Reference](#) 0 4

DIMEXE

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMEXE system variable is used to specify the distance that the dimension line extends the extension line.

Type	Real
Saved in	Drawing
Initial value	0.1800(Imperial) or 1.2500(Metric)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5348>